

MANUFACTURES OF INDUSTRIAL FILTER BAGS

Fluid Bed Drier bag Washing Instructions

Please Note

Remove any steel or hard plastic hooks that can damage the Filter bags.
Put the bag into the washing machine and wash it using the suggested washing powers below.

Washing powder Poly amide (Nylon) (PA)
1 to 2 g/l alkaline washing power

Washing powder for Polyester (PES)
1 to 2 g/l non –alkaline washing power
or
A 1 % Cleaning solution with a pH value <12.5
e.g. CIP COSA 92, Henkel

Washing Temperature max 40° C
Either hang the filter up to dry or dry it in the fluid bed drier machine.
Tumble-drying is not recommended.
Drying Temperature max 60°C